




Epson Perfection® V500 Photo



Unpack and remove protective tape.












2 Install software



Do not connect the USB cable yet.







Click **Install** and follow the on-screen instructions.

Windows Vista™: Click Run Epsetup.exe when prompted.

3 Connect and turn on




4 Scan a photo










Epson Scan scans your photo in **Full Auto Mode**. Wait for your scan to finish.



View your photo in Pictures or My Pictures.










Scanner Software Help

Click the Help button on your scanner software screen.



User's Guide

Double-click the Perfection V500P User's Guide icon on your desktop.

Epson Technical Support

Internet Support

Visit Epson's support website at **epson.com/support** and select your product for solutions to common problems for the Perfection V500 Photo. You can download drivers and documentation, get FAQs and troubleshooting advice, or e-mail Epson with your questions.

Speak to a Support Representative

U.S.: (562) 276-4382, 6 AM to 6 PM, Pacific Time, Monday through Friday

Canada: (905) 709-3839, 6 AM to 6 PM, Pacific Time, Monday through Friday

Toll or long distance charges may apply.

Software Technical Support

Adobe® Photoshop® Elements: Phone (800) 642-3623, www.adobe.com/support

ABBYY® FineReader®: (510) 226-6717, www.abbyyusa.com, support@abbyyusa.com





